



Certified under IECEx ITA 14.0009X
Part #: ME5070-2-99-151



Nautitech® 7.2V Battery Pack (Rev 3)

FEATURES AN INTEGRATED REAL-TIME-CLOCK FOR TIME
STAMPED EVENT DATA LOGGING WHICH CAN ASSIST
WITH ASSET MONITORING AND AUTOMATION

The RTC can be set using a double strength magnetic pen via the configuration panel on the Hawkeye display:

Location of magnetic switches / swipe keys:

The system provides four (4) swipe keys (**ENT**, **UP**, **DOWN**, **BACK**). The location of the magnetic “switches” for these keys is near the perimeter of the dial as indicated in image below. When a key is swiped, the name of the key appears on the status bar

- TO SWIPE:** Hover the magnetic pen over a “switch” and swipe it away
- UP/DOWN:** Used to change the selection OR adjust numeric value
- ENT:** Used to select an option OR adjust next value
- BACK:** Used to go to previous screen OR adjust previous value

To set the Real-Time-Clock:

1. Go to CONFIGURATION PANEL HOME and select “Set Date / Time”
2. Set YEAR, MONTH and DAY using **UP** and **DOWN** keys to select correct values
3. Swipe **ENT** to highlight the “Set Date & Time”
4. Use **ENT**, **UP**, **DOWN**, and **BACK** keys to set Hours, Minutes and Seconds in 24 hour time format
5. Swipe **ENT** again. Status bar will show “Settings Succeeded” and title bar should read the correct date and time